INSTRUCTIONS Angle Valve Repair Kit

Remove cap, ball, spring, washer, Teflon Seal, and stem from bottom. Install new stem and o-rings by inserting into valve body from top. (Rotating and lubricating the o-ring will help) Remove o-ring from the cap and install the new one provided. Install the Stainless Steel washer, Teflon seal, ball and spring with the cap and tighten snugly with a ¾" wrench. NOTE: SS washer is installed first followed by the seal etc.

INSTRUCTIONS Angle Valve Repair Kit

Remove cap, ball, spring, washer, Teflon Seal, and stem from bottom. Install new stem and o-rings by inserting into valve body from top. (Rotating and lubricating the o-ring will help) Remove o-ring from the cap and install the new one provided. Install the Stainless Steel washer, Teflon seal, ball and spring with the cap and tighten snugly with a ¾" wrench. NOTE: SS washer is installed first followed by the seal etc.

INSTRUCTIONS Angle Valve Repair Kit

Remove cap, ball, spring, washer, Teflon Seal, and stem from bottom. Install new stem and o-rings by inserting into valve body from top. (Rotating and lubricating the o-ring will help) Remove o-ring from the cap and install the new one provided. Install the Stainless Steel washer, Teflon seal, ball and spring with the cap and tighten snugly with a ¾" wrench. NOTE: SS washer is installed first followed by the seal etc.

INSTRUCTIONS Angle Valve Repair Kit

Remove cap, ball, spring, washer, Teflon Seal, and stem from bottom. Install new stem and o-rings by inserting into valve body from top. (Rotating and lubricating the o-ring will help) Remove o-ring from the cap and install the new one provided. Install the Stainless Steel washer, Teflon seal, ball and spring with the cap and tighten snugly with a ¾" wrench. NOTE: SS washer is installed first followed by the seal etc.

INSTRUCTIONS Angle Valve Repair Kit

Remove cap, ball, spring, washer, Teflon Seal, and stem from bottom. Install new stem and o-rings by inserting into valve body from top. (Rotating and lubricating the o-ring will help) Remove o-ring from the cap and install the new one provided. Install the Stainless Steel washer, Teflon seal, ball and spring with the cap and tighten snugly with a ¾" wrench. NOTE: SS washer is installed first followed by the seal etc.

INSTRUCTIONS Angle Valve Repair Kit

Remove cap, ball, spring, washer, Teflon Seal, and stem from bottom. Install new stem and o-rings by inserting into valve body from top. (Rotating and lubricating the o-ring will help) Remove o-ring from the cap and install the new one provided. Install the Stainless Steel washer, Teflon seal, ball and spring with the cap and tighten snugly with a ¾" wrench. NOTE: SS washer is installed first followed by the seal etc.

INSTRUCTIONS Angle Valve Repair Kit

Remove cap, ball, spring, washer, Teflon Seal, and stem from bottom. Install new stem and o-rings by inserting into valve body from top. (Rotating and lubricating the o-ring will help) Remove o-ring from the cap and install the new one provided. Install the Stainless Steel washer, Teflon seal, ball and spring with the cap and tighten snugly with a ¾" wrench. NOTE: SS washer is installed first followed by the seal etc.

INSTRUCTIONS Angle Valve Repair Kit

Remove cap, ball, spring, washer, Teflon Seal, and stem from bottom. Install new stem and o-rings by inserting into valve body from top. (Rotating and lubricating the o-ring will help) Remove o-ring from the cap and install the new one provided. Install the Stainless Steel washer, Teflon seal, ball and spring with the cap and tighten snugly with a ¾" wrench. NOTE: SS washer is installed first followed by the seal etc.

INSTRUCTIONS Angle Valve Repair Kit

Remove cap, ball, spring, washer, Teflon Seal, and stem from bottom. Install new stem and o-rings by inserting into valve body from top. (Rotating and lubricating the o-ring will help) Remove o-ring from the cap and install the new one provided. Install the Stainless Steel washer, Teflon seal, ball and spring with the cap and tighten snugly with a ¾" wrench. NOTE: SS washer is installed first followed by the seal etc.

INSTRUCTIONS Angle Valve Repair Kit

Remove cap, ball, spring, washer, Teflon Seal, and stem from bottom. Install new stem and o-rings by inserting into valve body from top. (Rotating and lubricating the o-ring will help) Remove o-ring from the cap and install the new one provided. Install the Stainless Steel washer, Teflon seal, ball and spring with the cap and tighten snugly with a ¾" wrench. NOTE: SS washer is installed first followed by the seal etc.