ROTOVAC and RV SWINGER GLIDE INSTRUCTION SHEET

- Remove the stainless cleaning heads/cups. Clean thoroughly and inspect the jets . Clean or replace jets as needed. Inspect felt ring seals and replace and/or clean as needed.
- Remove front wheel or raise it as high as possible off the carpet.
- Adjust rear wheels to the lowest point possible on the frame. If the rear wheels are very worn or they wobble, we highly suggest purchasing new wheels and/or bushings from Rotovac.
- This is a good time to thoroughly inspect your machine, tightening any loose screws and nuts, checking for clogs and obstructions, inspecting the motor brushes and oil and performing any maintenance needed. File the vacuum slots on the cleaning heads if they have become distorted, have any metal burrs or are dented.
- Align the slot inserts on the glide with the slots of the cleaning heads and press in, starting at one side of the outer ring, seat the glide to the face of the cleaning head. Do not use a hammer or mallet to seat the glides, as these could cause cracks or damage.
- Lay cleaning head on floor, glide down, and push down on the cleaning heads to ensure they are fully and evenly seated.
- Reinstall cleaning heads on machine. Cups should touch each other, but still spin without bogging the motors at all.
- QUESTIONS or CONCERNS with the installation or use of your ROTOVAC glides? Call the toll free GREENGLIDES support line 6am to midnight PST, 7 days a week:
- 866-GET-TEFLON (866-438-8335)