GREENGLIDES CASTEX, WHITE MAGIC SINGLE JET, PROCHEM 3 JET AND PROCHEM SINGLE JET INSTRUCTION SHEET

- FOR THE CASTEX WAND ONLY: Remove the stainless steel lips from your wand.
- Due to the design of these wands, with no external lips and a variable internal slot, the glide must be affixed to the wand with a good quality adhesive / sealant. We recommend and use GOOP Brand Household Adhesive and Sealant.
- Clean wand head well and lightly scuff with ultra fine sand paper on the outer slot area at least 1-½" up, front and back.
- Place the glide on the lips of the wand and press on until the wand lips are fully seated in the bottom of the glide channel and the glide is centered on the wand.
- Clamp or tape the glide firmly in position on the wand. Make sure you still allow yourself access to the areas to be sealed!
- Run a bead of GOOP along the front and back edges of the glide. Do not GOOP the ends of the glide.
- Place the wand in the cleaning position and allow the sealant to cure for at least eight hours, preferably 24 hours.
- After the GOOP is fully cured, check for any areas that might need a reapplication. Apply more GOOP as needed and allow to cure.
- Use wand as normal.
- Inspect the integrity of the adhesive frequently and remove and reapply the GOOP as needed.
- Use the provided cleaning tool to ream out the holes in your glides, this keeps them round and free of debris, thereby maximizing the performance of your glides.
- QUESTIONS or CONCERNS with the installation or use of your glide? Call the GreenGlides helpline at 1-866-GET-TEFLON (1-866-438-8335)

GREENGLIDES CASTEX, WHITE MAGIC SINGLE JET, PROCHEM 3 JET AND PROCHEM SINGLE JET INSTRUCTION SHEET