GREENGLIDES
RX20
HIGH EFFICIENCY STAR CONVERSION KIT INSTRUCTIONS

- Remove High Efficiency star from RX20, clean star and RX20 thoroughly.
- Remove the nuts from the threaded rods which affix each skid to the vacuum chambers. There are two on each skid.
- Carefully remove the skids, taking care to avoid damaging the gaskets. Thread the stock nuts back onto the stock skids and store them in a safe place. Normally the gasket will remain stuck to the vacuum chambers, this is fine, leave them there.
- Gently wipe the skid-side surface of the gasket clean. If the gasket doesn't remain stuck to the vacuum chamber, clean it and reposition it properly on the vacuum chamber.
- Place the new stainless steel Conversion Kit skids on the vacuum chambers using the new lock nuts provided with your kit. Tighten the nuts securely. Take care not to overtighten or crossthread the nuts.
- Trim away any gasket material that protrudes into the vacuum slot. Gasket material in the vacuum slot will catch debris and severely hinder airflow.
- Install Teflon GreenGlides according to instructions provided with glides.
- Reinstall star on RX20 as normal.
- DO NOT OPERATE RX20 WITH CONVERSION SKIDS WITHOUT TEFLON GLIDES INSTALLED! THIS COULD POSSIBLY DAMAGE THE MACHINE OR THE CARPETED SURFACE!!!
- Questions or concerns with the installation or use of your Conversion Kit? Call GreenGlides technical support at: 866-GET-TEFLON (866-438-8335) 7am-10pm PST 7days.