GREENGLIDES RX20, POWERGLIDE INSTRUCTION SHEETS

- Trim any gasket that may be protruding into the vacuum slot of each skid.
- Press the stem of the glides into the vacuum slots of the skids, or if you have one, use a rubber mallet. They should fit very firmly and seat well.
- If a glide is not seating well, the cause is usually an irregular weld on the skid. Trim the Teflon to allow the glide to seat fully onto the skid.
- Run the machine as usual.
- The glides may be removed by GENTLY prying up from one end with a flat head screwdriver.
- At least once a month, or as uneven wear is noticed, remove glides and reinstall facing the opposite direction. Wear tends to be greatest on the outside edges of the skids, flipping them around will greatly extend the life of your RX20 glides. Also, if most of your work is on thin, apartment grade carpets, occasionally run the glides on a thin gluedown commercial. This will burnish and smooth the scratches that tack strip causes.
- Use the provided cleaning tool to ream out the holes in your glides. This keeps them round and free of debris, thereby maximizing the performance of your glides.
- QUESTIONS or CONCERNS with the installation or use of your RX20 or PowerGlide glides? Call the GreenGlides helpline at 1-866-GET-TEFLON (1-866-438-8335)

GREENGLIDES RX20, POWERGLIDE INSTRUCTION SHEETS