GREENGLIDES STEAMWAY JET ADJUSTMENT INSTRUCTION SHEET

- Loosen the two screws that secure the brass jet manifold assembly
- Loosen the valve hanger screws, and move the valve assembly forward as well as the hard solution line and the jet manifold assembly will move down putting the Jet closer to the carpet, you want it all the way down, this will minimize overspray.
- Retighten the valve assembly
- Place your fingers up inside the heat chamber and hold the jet manifold backing plate, and remove the two screws holding the jet manifold in place.
- Reassemble the jet manifold, replacing the old 1¼" screws with the enclosed 1½" screws. Place the 2 nylon spacers on the screws between the BRASS jet manifold and the wands rear steel plate, in such a way as to bring the jet toward the rear of the wand and to bring the spray pattern off the Teflon glide slightly, Retighten with new screws and spacers in place.
- QUESTIONS or CONCERNS with the installation or use of your Steamway glides? Call the GreenGlides helpline at 1-866-GET-TEFLON (1-866-438-8335)